

# Royal Enfield Twin 12000 Mile Maintenance

	12000 mile maintenance	GT/INT
1	Change engine oil and filter, clean magnetic drain plugs	
2	Inspect and adjust valve clearance <b>In .08mm Ex .18mm</b>	
3	Replace spark plug	
4	Inspect spark plug wires	
5	Inspect rubber hose air filter to throttle body	
6	Inspect rubber hose inlet manifold/adapter	
7	Inspect rubber hose emission related components	
8	Replace fuel filter	
9	Replace air filter element	
10	Inspect vent pipe under air filter box	
11	Inspect secondary air hose	
12	Adjust throttle cable free play	
13	Adjust clutch cable freeplay	
14	Lubricate hand lever pivot points	
15	Inspect brake pads/Calipers Front and Rear	
16	Replace brake fluid	
17	Lubricate brake lever and gear shifter pivot points	
18	Inspect brake lines/banjo bolt fittings	
19	Inspect front forks for leakage	
20	Inspect steering head movement	
21	Clean lube and adjust rear drive chain	
22	Inspect spoke tightness/rim runout	
23	Clean and tighten battery terminal connections	
24	Inspect tire condition/wear level	
25	Lubricate side stand/center stand	
26	Lubricate foot rest pivots	
27	Inspect critical fasteners for tightness	
28	Inspect ground terminals/tighten	
29	Test ride	

Thank you from your Royal Enfield Technician \_\_\_\_\_